



PRODUCT ADVISORY

Changes to the HulaPoint™ Pointing Device

Do Not Over-Force Device

iKey's HulaPoint II™ pointing device is now a stationary resistive strain gauge that does not contain any moving parts, unlike its predecessor, the HulaPoint™. This device has been upgraded to improve performance and durability, offering greater sensitivity and more control.

To operate: *It is not necessary to apply extreme force for results.* Place finger firmly in the center of the pointing button and apply slight pressure in the direction you want the cursor to move. The more pressure applied, the faster the cursor will react. To adjust cursor speed, you may need to change the mouse settings in your operating system.

If you have any questions, please call us at (800) 866-6506, or visit www.ikey.com.